EN

ACCURIZE

www.accurizetarget.com





Warning!
Avoid direct eye exposure Laser light. Keep away from children.

USER MANUAL
LASER ACOUSTIC MODEL

1. **Never look directly at the laser. Never direct it to other people or animals. The laser can damage the eye.**
2. Align the laser at a wall, ceiling, or floor.
3. Hold the black button for about 1,5 sec, one flash of light should appear on the wall, the ceiling, or the floor. (Not only tap the black button, but hold it for 1,5 sec)
4. Check that the firearm is not charged with ammunition.
5. Check that the firearm is in dry fire mode if using air rifle/pistol. DO NOT OPEN THE AIR VALVE.
6. The laser pin is inserted into the barrel from the mouth of the weapon until it is physically stopped. If it goes very tight, lubricate a little gun oil on the O-rings.
7. The laser is now ready to be used and will send laser shots to the target by pull-out, and at charge grips carried out after the time limit, NB! **see bottom.**
8. (Use the middle target to calibrate the biathlon target.)
9. Press the black button 5-6 sec and 5 quick flashes of light should be observed on the floor, ceiling, or wall. **The laser is then turned off.**
10. The laser should **ALWAYS** be removed from the firearm after use. Do not forget it before using sharp ammunition.

Replacing the Battery
The battery (CR1620) is commercially available. It can be replaced by turning the upper part of the laser. You can use a thin object to carefully push it out from the back.

NB! ***The laser will fire after the sound from the firing pin***

- *The laser will fire again when you pull back the bolt – if you do not do it before 0,6 seconds*
- *If you do it before 0,6 seconds, the laser will not fire before the firing pin hit again.*

Information to those who use the Accurize shooting system: If you want more delay to do the "pull back bolt action" - use the inhibit function in the app itself.