# ACCURIZE MINI

User Manual




WWW.ACCURIZETARGET.COM

ACCURIZE
SHOOTING SYSTEM

ACCURIZE
SHOOTING SYSTEM

# User Manual **Accurize** MINI

**PACKING LIST**

Target screen / USB connecting cable /Holder






**BATTERY CHARGE**

Charge the battery to full before using the target

- Connect the charger to the front of the screen
- Connect the charger to the main power
- The red lamp will start flashing
- Green light will appear when fully charged

ACCURIZE MINI is a target screen with timer for measuring a shooters reaction and the accuracy .
Each session is 10 shot on a single target. If you use several targets , the system will choose which target to hit random and a session is still 10 shot.
After 10 shot the timer will show each shots reaction time and a total time for the 10 shot session.
This is a great tool to practice trigger control , balance, speed and accuracy in a stressful session

**STEP 1.**

**There is two- wheel switch on the back of the screen with an arrow indicator on the switch**

**1.Select group**

**2.Select node/screen**

**The Group switch indicate if you want to have different group set up at the same time, this can be useful if you want a total time result for each group after each session.**

**The primary/node switch needs to be adjusted if you are using more than one target screen in your session. The main screen is always number 1 , next is number 2 ,next is number 3 and so on.**

**STEP 2.**

**Press the grey button on the front of the screen to turn it ON.**

**If you are using more than one screen , start by turning on the main screen**

**A timer will start on each screen and the main screen will count down from 10 to 0.**

**A green light and a sound will appear on the screen that you are supposed to hit.The timer will count the time until the screen has registered a hit.(max time is 3 second )**

**This will reoccur at random on your screens until the 10 shots serie is over.There will be 3 seconds in between the changing of screens.**
**After the session is over , the main screen will show the time used for each shot and a total time spent for all 10 shots.**
**STEP 3.**
**To start a new session tap the main screens grey button shortly, do not hold the button in.**
**To turn OFF all the targets in use ,hold the main screen grey button for 3 seconds. All targets will be now be in OFF position.**

**If question go to WWW.ACCURIZETARGET.COM contact form**